

SANBY

AUTO STAMP

Instruction Manual

Please read before use the products.

Product Features

- Stamping continually without stamp pad required
- Clean and clear impressions due to automatically inking each time stamping
- Compact size, portable anywhere
- Re-ink easily, long-time usable after re-ink

How to Re-ink

- (1) Place the stamp in the direction as shown, then gradually press an end of the stamp body inside towards the arrow direction until the rubber stamp face turns up horizontally.



- (2) Drop and apply ink onto the entire area of the rubber stamp face. Take care not to re-ink excessively.



- (3) Gradually release until the rubber stamp face turns to contact the ink pad inside the body. Then ink will be absorbed and kept by ink pad for future use.

- (4) Repeat step (1) – (3) two or three times, then check the imprint conditions by stamping on the paper.

- ※ Use auto stamp's ink only.
- ※ Other inks have different chemical compositions that may cause damage of ink pad.

How to Clean Rubber Stamp

If dirt is sticking to the rubber stamp face, use the below methods to remove.

- Attach adhesive tape softly to the area of rubber stamp face that dirt is sticking. Then pull the tape out in order to make dirt stick to the adhesive tape instead.
- In case of dirt sticking tightly, use cotton bud to remove. Take care not to touch the rubber stamp forcefully. It may cause damages on the surface of rubber stamp.

Precautions

- If ink gets on your hand or skin, clean up quickly by soap and water. If ink gets into your eyes, rinse the eyes thoroughly with water immediately and see doctor urgently.
- If ink gets on your clothes, it may not come off. Please use carefully.
- Keep away from sparks, heat or high humidity.
- Keep out of the reach of children.
- Please do not use for other purposes except for stamping on paper.
- Some kinds of paper cannot absorb ink or may cause ink spreading over it, such as tracing paper, blotting paper, parchment paper etc. Please avoid stamping on them.
- Stamping on non-carbon copy paper or thermal paper may cause discoloring or deforming of imprint.

Distributed by

SANBY (THAILAND) CO., LTD.

443, Moo 17, Bangplee Industrial Estate Soi 6/1,
Bangna-Trad Rd., T.Bang Sao Thong,
A.Bang Sao Thong, Samut Prakan, Thailand 10570